### **General Safety Information**

## **▲** WARNING

- Before use, check the wheels to make sure that there are no bent or loose spokes, dents, scratches or cracks on the rim surface. Do not use the wheel if any of these problems are found.
- Do not use in combination with bottom link-type suspension forks. With these types
  of forks, the clearance between the hub axle and the brake shoes can change due
  to the operation of the suspension, so that when the brakes are applied, the brake
  shoes may touch the spokes.
- If the quick release mechanism is not used correctly, the wheel may come off the bicycle and serious injury could result. Read the Service Instructions for the quick release mechanism thoroughly before use.
- These wheels are designed for riding on paved surfaces. If the wheels are used on unpaved surfaces, the wheels may become bent or damaged, and accidents may result.
- Check that the wheels are fastened securely before riding the bicycle. If the wheels
  are loose in any way, they may come off the bicycle and serious injury may result.
- The hollow on the opposite side to the valve hole is an indicator for the amount of rim wear. If this hollow can no longer be seen, stop using the rim.
   If you continue using the rim, it may break, and the bicycle may fall over and an accident may result.
- Obtain and read the service instructions carefully prior to installing the parts.
   Loose, worn or damaged parts may cause the bicycle to fall over and serious injury may occur as a result. We strongly recommend only using genuine Shimano replacement parts.
- Read these Technical Service Instructions carefully, and keep them in a safe place for later reference.

# ▲ CAUTION

- The tires should be inflated to a suitable pressure before use.
- If using rims with clincher tires, use rim tape or spoke hole plugs for a rim size of 18-622 and which can withstand high pressures, otherwise the tires may suddenly puncture and come off, and severe injury may result. Furthermore, it is not recommended that you reuse rim tape or spoke hole plugs after they have been removed from the wheel. If the tape or plugs are reused, the tires may suddenly puncture and come off, and severe injury may result.

## CAUTION

- The Shimano R55HC (high performance) brake shoes use an aggressive compound designed with an emphasis on maximum performance in wet conditions, however they will cause accelerated rim wear.
- Shimano accepts no responsibility for reduced rim life which might occur from using R55HC brake shoes.
- Use of genuine Shimano spokes and nipples is strongly recommended. If genuine Shimano parts are not used, the hubs or rims may become damaged.
- Before use, check that there are no pieces of metal or other foreign objects sticking to the brake pads. If any such items are present, they may cause damage to the rim when the brakes are applied.
- The nipples have large diameters and are easy to rotate in order to make it easier
  to increase the spoke tension. However, be careful not to overtighten the nipples
  when adjusting the spoke tensions. If the nipples are overtightened, damage to the
  rim may result.
- (We recommended that you ask authorized bicycle dealers to make the adjustments.)

#### Note

- If the wheel becomes stiff and difficult to turn, you should lubricate it with grease.
- Do not apply any oil to the inside of the hub, otherwise the grease will come out.
- Special spoke wrenches are available as optional accessories.
- We recommend that you ask authorized bicycle dealers to adjust the spoke tensions if there is any initial play in the spokes and after the first 1,000 km of riding.
- Spoke protectors (CP-WH23) are also sold separately. Please ask your bicycle dealer for details.
- For maximum performance we highly recommend Shimano lubricants and maintenance products.
- Reflectors (manufactured by CATEYE) are also sold separately. Please ask your bicycle dealer for details.
- < For front >

Model number	Specification	Color
RR-550-WUW/W SMN03	CPSC	White
RR-550-WUA/A SMN03	AS	Amber
RR-317-WUA/4K SMN03	DIN	Amber
< For rear >		
Model number	Specification	Color
RR-550-WUWSW W/O BRACKET	CPSC	White
RR-550-WUASW W/O BRACKET	AS	Amber
BR-317-WUASW W/O BRACKET	DIN	Amber

 Parts are not guaranteed against natural wear or deterioration resulting from normal use.

In order to realize the best performance, we recommend that the following combination be used.

Applicable tire size		Clincher tire	
		700C (19C - 28C)	
Wheel		WH-R500	
Chain	9-speed	CN-7701 / CN-HG93 / CN-HG73	
	8-speed	CN-HG50	
Cassette sprocket	9-speed	CS-6500 / CS-HG70-9 / CS-HG50-9	
	8-speed	CS-HG70-8 / CS-HG50-8	
Largest sprocket		21 - 27T	

WH-R500

9/8

700C

Χ

#14 BC2.0

20.8 mm

**Specifications** 

Clincher

Model number

Applicable tires

Applicable nipples

Speeds

Rim size

Rim width

## Technical Service Instructions SI-4BG0B-001

WH-R500


Wheel

# Spoke lacing

Lace the spokes as shown in the illustration.


#### (For front)

At the front, a radial assembly is used at both the left and right.



#### (For rear)

At the rear, a tangent assembly is used at the both left and right.



	Spoke tension value				
	For front	For rear			
800 - 1200 N (180 - 270 lbf)	900 1000 N	Right (sprocket) side	Left side		
	900 - 1500 N (202 - 337 lbf)	500 - 1000 N (112 - 225 lbf)			

<sup>\*</sup> These values should be used as a guide only.

## Installation of the HG sprockets

For each sprocket, the surface that has the group mark should face outward and be positioned so that the wide parts of the gear projections on each sprocket and the A part (where the groove width is wide) of the freewheel body are aligned.





wide at one place only.



For installation of the HG sprockets, use the special tool (TL-LR15) to tighten the lock ring.
To replace the HG sprockets, use the special tool (TL-LR15) and

 To replace the HG sprockets, use the special tool (TL-LR15) and TL-SR21 to remove the lock ring.





Tightening torque: 30 - 50 N⋅m

{261 - 434 in. lbs.}


# Replacement of the freewheel body

After removing the hub axle, remove the freewheel body fixing bolt (inside the freewheel body), and then replace the freewheel body.

#### Note:

Do not attempt to disassemble the freewheel body, because it may result in a malfunction.

Tightening torque: 35 - 50 N·m {305 - 434 in. lbs.}



## SHIMANO

SHIMANO AMERICAN CORPORATION
One Holland Tryine, California 97618, U.S.A., Phone: +1-949-951-5003

SHIMANO EUROPE B.V.
Industrieweg 24, 8071 CT Nunspeet, The Netherlands Phone: +31-341-272222

SHIMANO INC.

3-77 Oimatsu-cho, Sakai-ku, Sakai-shi, Osaka 590-8577, Japan

Please note: specifications are subject to change for improvement without notice. (English) © Jan. 2009 by Shimano Inc. XBC IZM Printed in Malaysia