



Front Hub (for Disc Brake)



User's manuals in other languages are available at :
<http://si.shimano.com>

IMPORTANT NOTICE

- Contact the place of purchase or a bicycle dealer for information on installation and adjustment of the products which are not found in the user's manual. A dealer's manual for professional and experienced bicycle mechanics is available on our website (<http://si.shimano.com>).
- Do not disassemble or alter this product.


For safety, be sure to read this user's manual thoroughly before use, and follow them for correct use.

Important Safety Information

Guidelines that require replacement, contact the place of purchase or a bicycle dealer.

⚠ WARNING

- Check that the wheels are fastened securely before riding the bicycle. Using the quick release lever incorrectly may cause the wheel to fall off, etc. and lead to serious injury due to a fall.
- If the quick release mechanism is not used correctly, the wheel may come off the bicycle and serious injury could result. Read the user's manual for the quick release mechanism thoroughly before use.
- If the quick release lever is on the same side as the disc brake rotor, there is the danger that it may interfere with the disc brake rotor. Make sure that even if the quick release lever is tightened with your palm with all your strength, the quick release lever does not interfere with the disc brake rotor. If the lever interferes with the disc brake rotor, stop using the wheel and consult a dealer or an agency.
- After reading the user's manual carefully, keep it in a safe place for later reference.



Note


- Do not apply any oil to the inside of the hub. Otherwise, the grease will flow out.
- Use a neutral detergent when cleaning hubs. Other cleaners may damage the hubs. Do not clean any areas that have been instructed not to be cleaned.
- Do not clean the hub areas with a high-pressure wash. Water may get inside the hubs, which can degrade performance.
- Products are not guaranteed against natural wear and deterioration from normal use and aging.
- For maximum performance we highly recommend SHIMANO lubricants and maintenance products.

Regular inspections before riding the bicycle

Before riding the bicycle, check the following items. If any problems are found with the following items, contact the place of purchase or a bicycle dealer.

- Are the wheels fixed?
- Do the wheels rotate smoothly?
- Are there any abnormal noises?

Names of parts

A

Moyeu avant(pour frein à disque)



Des manuels de l'utilisateur sont disponibles dans d'autres langues à :
<http://si.shimano.com>

AVERTISSEMENT IMPORTANT

- Pour tout renseignement supplémentaire concernant l'installation et le réglage, prière de contacter le lieu d'achat ou un revendeur de bicyclettes à proximité. Un manuel du revendeur est également disponible sur notre site Web (<http://si.shimano.com>).
- Ne pas démonter ou modifier ce produit.


En ce qui concerne la sécurité, veiller à bien lire ce manuel de l'utilisateur avant l'utilisation et à bien le suivre pour une utilisation correcte.

Informations générales concernant la sécurité

Veillez contacter le lieu d'achat ou le revendeur de la bicyclette pour les instructions relatives au remplacement.

⚠ AVERTISSEMENT

- Assurez-vous que les roues sont bien serrées avant d'utiliser le vélo. Utiliser le levier de déblocage rapide incorrectement pourrait entraîner le détachement de la roue, etc. et conduire à des blessures graves suite à une chute.
- Si le mécanisme de relâchement rapide n'est pas correctement utilisé, la roue peut se séparer de la bicyclette et des blessures graves peuvent s'ensuivre. Consultez le manuel d'utilisation pour connaître la procédure à suivre avant d'utiliser le mécanisme d'enclenchement.
- Si le levier à blocage rapide se trouve du même côté que le rotor de frein à disque, ces deux éléments risquent d'entrer en contact. En appuyant de la main de toutes vos forces, assurez-vous que le levier à blocage rapide est bien serré et ne touche pas le rotor de frein à disque. Si le levier touche le frein à disque, arrêtez d'utiliser la roue et consultez un revendeur ou intermédiaire.



- Après avoir bien lu le manuel de l'utilisateur, le ranger dans un endroit sûr pour référence ultérieure.

Remarque

- N'appliquez pas d'huile à l'intérieur du moyeu. Sinon, la graisse s'en échappera.
- Utilisez un détergent neutre pour nettoyer les moyeux. Les autres produits de nettoyage risquent de détériorer les moyeux. Ne nettoyez aucune zone qu'il est demandé de ne pas nettoyer.
- Ne nettoyez pas la zone du moyeu avec un nettoyeur à haute pression. L'eau risque d'entrer dans les moyeux, ce qui peut diminuer leur performance.
- Les produits ne sont pas garantis contre l'usure et la détérioration naturelle du fait d'un usage normal et du vieillissement.
- Afin de préserver au maximum les performances, nous recommandons fortement l'utilisation de lubrifiants et de produits d'entretien SHIMANO.

Inspections régulières avant de conduire la bicyclette

Avant de conduire la bicyclette, vérifier les articles suivants. Si l'un des articles suivants présente un problème, contacter le lieu d'achat ou un revendeur de bicyclettes.

- Les roues sont fixées?
- Est-ce que les roues tournent doucement?
- Y a-t-il des bruits anormaux?

Nom des pièces

A

SHIMANO

SHIMANO NORTH AMERICA BICYCLE, INC.
One Holland, Irvine, California 92618, U.S.A. Phone: +1-949-951-5003

SHIMANO EUROPE B.V.
High Tech Campus 92, 5656 AG Eindhoven, The Netherlands Phone: +31-402-612222

SHIMANO INC.
3-77 Oimatsu-cho, Sakai-ku, Sakai City, Osaka 590-8577, Japan

Please note: specifications are subject to change for improvement without notice. (English)
Sous réserve de changement des spécifications sans préavis pour l'amélioration du produit. (French)
© Dec. 2023 by Shimano Inc. ITP