### SERVICE INSTRUCTIONS

Before use, read these instructions carefully, and follow them for correct use.


Front Derailleur FD-M351



# **EXAGE**


### **Assembly to Frame**

 Set the front derailleur while the Biopace crank is in a direct line with the seat tube.



- The outside surface (A) of the chain guide should be directly above and parallel to the large gear.
- 3. Secure by using a 5mm Allen key.

Tightening torque: 50kgfcm (43 in.lbs)




### ■Specifications

Installation band diameter	Band type∅28.00 ~ ∅28.60mm (1-3/32" ~1-1/8")	
	EC-type (End-less clamp ty ∅31.8mm (1-1/4")	/pe)
Stoke (A – A')	Band type34 ~ 54mm (1-11/32" ~ 2-1/8")	Φ A'
	EC-type35 ~ 55mm (1-3/8" ~ 2-5/32")	1
Application	For use with front chain- wheel triple gear only.	

## Adjustment and Cable Attachment

#### 1. Low adjustment

Adjust the clearance between the chain guide's inner plate and the chain to 1 mm—1.5 mm.




#### 2. Cable attachment

Tighten the cable fixing bolt to fix the cable. Secure by using a 5mm allen key.

Tightening Torque: 50kg/cm (43 in.lbs)

#### 3. Top adjustment

Set the chain guide outer plate to the smallest gap at which the chain guide does not contact the chain.



Please note: specifications are subject to change for improvement without notice, (English)

